

Casio	Ref.
A-158WA	70625118
A-158WEA	70625118
A-163WA	70625118
A-164WA	70625118
A-166WA	70625118
A-167WA	70625118
A-168WA	70641447
A-168WEC	70641447
A-168WG	71605996
A-168WG-9E	10008114
A-168WGA	71605996
A-42H-1B	10040373
ABX-21	70643624
AD 520C-1B	70368314
AD 520C-1E	70368314
AD 520C-7B	70368314
AD 520C-9E	70368314
AD-300-1E	70622792
AD-300-N1E	70622792
AD-S800WH-2A	10478118
AE-1000W	10517248
AE-1000W-1A	10347820
AE-1000W-1B	10347820
AE-1000WD-1A	10300672
AE-1100W-1A	10347820
AE-1100W-1B	10347820
AE-1200WH-1A	10365960
AE-1200WH-1B	10365960
AE-1200WHB-1B	10438123
AE-1300WH-1A	10365960
AE-1300WH-1A2	10365960
AE-1300WH-2A	10365960
AE-1300WH-4A	10365960
AE-1300WH-8A	10365960
AE-2000W-1	10302043
AE-2100W	10302043
AE-30W-1	70607875
AE-30W-9	70607875
AEQ-110BW-9A	10410723
AEQ-110W-1A	10410723
AEQ-110W-1A2	10410723
AEQ-110W-1A3	10410723
AEQ-110W-1B	10410723
AEQ-110W-2A	10410726
AEQ-200W-1A	10527633
AEQ-200W-2A	10527633
AEQ-200W-9A	10527633
ALT-6000-1	70621707
ALT-6000-N1	70621707

Casio	Ref.
AMW 320C-1E	70368314
AMW 320C-7E	70368314
AMW 320C-9E	70368314
AMW 320CX-7E	70368314
AMW 320D-1B	70368314
AMW 320D-1E	70368314
AMW 320D-7B	70368314
AMW 320D-9E	70368314
AMW-320-1A	10406455
AMW-320D-1B	70368314
AMW-320R-1E	10406454
AMW-320R-7E	10406454
AMW-320R-9E	10406454
AMW-330B-1A	10406454
AMW-340-1A	10318687
AMW-340-9A	10318687
AMW-380-7A	10452240
AMW-700-1A	10198354
AMW-700-1A	10224048
AMW-700B-1A	10198354
AMW-702-7A	10239913
AMW-702D	10239912
AMW-704-7A	10239924
AMW-704D-7A	10239923
AMW-705D-1A	10239923
AMW-706D-7A	10239923
AMW-706D-7A1	10239924
AMW-710-1A	10347967
AMW-710B-7A	10347957
AQ-150W-1B	71607574
AQ-150W-2B	71607577
AQ-160W-1B	10137491
AQ-160W-7B	10137492
AQ-160WD-1B	10137469
AQ-160WD-2B	10137469
AQ-160WD-7B	10137469
AQ-161W	10137491
AQ-161W-2	10137506
AQ-161WB-1	10137508
AQ-163W-1B1	10137491
AQ-163W-1B2	10137491
AQ-163W-2	10137506
AQ-163W-7B1	10137491
AQ-163W-7B2	10137491
AQ-163WG-1B	10137491
AQ-164W-1A	10285465
AQ-164W-7A	10285465
AQ-180W-1B	10212268

Casio	Ref.
AQ-180W-7B	10212268
AQ-180WD-1	10212271
AQ-190-1A	10330835
AQ-190W-1A	10330835
AQ-190WD-1A	10331223
AQ-222A-1D	70637562
AQ-222A-7B	70637562
AQ-222A-7D	70637562
AQ-22-4E	10224223
AQ-22-8B	10224223
AQ-230A-1A	10339806
AQ-230A-7B	10339806
AQ-230GA-9B	10339807
AQ-231A-7B	70637562
AQ-231AMV-7B	70637562
AQ-231AMV-7E	70637562
AQ-23-1BZ	10224223
AQ-315A-1D	70637562
AQ-38-2EZ	10224223
AQ-45-1E	70603451
AQ-45-7B	70603451
AQ-45-7E	70603451
AQ-46-8A	70603451
AQ-46-9A	70603451
AQ-47	71607394
AQ-47-1E	71607394
AQ-47-7E	71607394
AQ-47-9E	71607394
AQ-48	71604010
AQ-E10-1B	10057292
AQ-E10-1E1	10057292
AQ-E10-1E2	10057292
AQ-E10-7E	10057292
AQ-E10G-7E	10057292
AQF-100W-7B	10216858
AQF-102W-1	10254192
AQF-102W-7	10254192
AQ-S800W-1B	10395812
AQ-S800W-1B2	10395812
AQ-S800W-1E	10395812
AQ-S810-2A	10410726
AQ-S810W-1A	10410723
AQ-S810W-1A3	10410723
AQ-S810W-1B	10410723
AQ-S810W-3A	10410730
AQ-S810WC-4A	10452159
AQW-100-1A	10300664
AQW-100D-1A	10300672
AQW-101D-1A	10300672

Casio	Ref.
AQW-5-1E	70374318
AQW-5-1E2	70374318
AQW-5-7E	70374318
ARW-320AT-1B	70607028
ARW-320AT-1E1	70607028
ARW-320AT-1E2	70607028
ARW-320AT-N1B	70607028
ARW-32-1E3	70604067
ARW-32-1E4	70604067
ARW-32-7E2	70604067
AW-1G	70604067
AW-20-1G	70604067
AW-20-7G	70604067
AW-30	70634251
AW-302	70612257
AW-34	70634251
AW-360	71604106
AW-43	70634251
AW-48H-1B	10140392
AW-48H-1E	10140392
AW-48H-7B	10140392
AW-48H-7E	10140392
AW-48HE-1A	10140392
AW-48HE-7A	10140392
AW-49H-1B	10160334
AW-49H-1E	10160334
AW-49H-7B	10160334
AW-49H-7E	10160334
AW-49HE-1A	10160334
AW-49HE-2A	10160334
AW-49HE-7A	10160334
AW-560D-7C	10243638
AW-560E-1A	10243638
AW-590-1A	10273059
AW-590BL-1A	10303924
AW-590BL-5A	10303925
AW-591-2A	10273059
AW-591-4A	10273059
AW-591CL-1	10287187
AW-591MS-1A	10277802
AW-80-1A	10117230
AW-80-1A2	10117230
AW-80-2B	10117230
AW-80-4B	10117230
AW-80-7A	10117230
AW-80-7A2	10117230
AW-80-9B	10117230
AW-80D-1A	10117233
AW-80D-1A2	10117233

Casio	Ref.
AW-80D-2A2	10117233
AW-80D-7A2	10117233
AW-80V-1B	10220479
AW-80V-3B	10220461
AW-81-1A1	10194983
AW-81-1A2	10194983
AW-81-7A	10194983
AW-82-1A	10117230
AW-82D-7A2	10483647
AW-90H-2B	10379447
AW-90H-7B	10379447
AW-90H-7E	10379447
AW-90H-9E	10379447
AW-E10-1E	10064853
AW-E10-7B	10064853
AW-E10G-7EVWC	10064853
AWG-100-1A	10273059
AWG-100R-1A	10273059
AWG-101-1A	10273059
AWG-101F-4A	10273059
AWG-M100-1AD	10273059
AWG-M100A-1AD	10273059
AWG-M100B-1AD	10273059
AWG-M100F-1AD	10273059
AWR-M100-1AD	10273059
AW-S90-1A1	10134116
AW-S90-1A2	10134116
AW-S90-7A	10134116
AW-S90-9A	10134116
AWS90D-1A	10134117
AWS90D-2A	10134117
AWS90D-4A	10134117
AWS90D-7A	10134117
B-614WA-1	70637562
B-640WB-1A	10409334
B-640WB-1B	10409334
B-640WB-2B	10409334
B-640WB-3B	10409334
BA-1005A-7D	10443262
BA-110-7A1	10451765
BA-110-7A3	10451765
BA-110BC-2A	10471072
BA-110LB-7A	10451765
BA-111GGA-7A	10451765
BA-112-7A	10451765
BA-120LP-7A2	10451765
BEM-308	10427209
BG-1001-1V	10239576
BG-1006SA-8	10361932

Casio	Ref.
BG-1221-1	10220590
BG-1222G-1	10220590
BG-1224B-4W	10272733
BG-1302-2	10287393
BG-141V	10116093
BG-142	71606417
BG-145-2	1011100
BG-145V-1	1011100
BG-152-2B	10108300
BG-152-3B	10108300
BG-152-4B	10108300
BG-163-4	10069706
BG-169A-6	10148910
BG-169A-8	10148912
BG-169DB-4	10287179
BG-169R-2B	10353073
BG-169R-6	10148910
BG-169R-6D	10148910
BG-169R-8	10148912
BG-169R-8B	10148912
BG-169R-8D	10148912
BG-2000-1W	10260327
BG-3000-1	10290521
BG-3000-1D	10290521
BG-3000-2	10330706
BG-3000-2D	10330706
BG-3000-7A	10290522
BG-3000-8	10290528
BG-3000-8B	10290528
BG-3000-8C	10290528
BG-3000A-1	10290521
BG-3000A-1D	10290521
BG-3000A-7	10290522
BG-3000J-1	10290521
BG-3000M-7	10290522
BG-3002V -2B	10301681
BG-5600-7	10208678
BG-5600WH-7	10208678
BG-6900-7	10427860
BG-6901-7W	10427866
BG-6903-1	10400807
BG-6903-7	10427860
BG-6903-7B	10427860
BGA-1000-1B	10309270
BGA-100-1B	10309270
BGA-100-7B	10309272
BGA-100-7B2	10320173
BGA-101-1B	10309270
BGA-101-7B	10309272

Casio	Ref.
BGA-1020-7B	10309272
BGA-102-7B	10309272
BGA-103-1B	10309270
BGA-104-7B	10309272
BGA-107-1B	10309270
BGA-1100-7B	10290522
BGA-110-1B2D	10290521
BGA-110-7B2	10290522
BGA-1110GR-1B	10290521
BGA-113-7B	10290522
BGA-114-8B	10290528
BGA-116-7B	10290522
BGA-141-1B2	10309270
BGA-161-3B	10450985
BGA-200-1E	10316342
BGA-200PD-1B	10316342
BGA-230-3B	10534710
BGD-1000-1	10316342
BGD-100-1	10316342
BGD-1020-1	10316342
BGD-102-1	10316342
BGD-110-1	10322650
BGD-110-1B	10322650
BGD-110-7	10322643
BGD-110-7B	10322643
BGD-110M-7	10322643
BGD-120P-7B	10349444
BGD-1300-7B	10309272
BGD-140-1A	10400807
BGD-140-7B	10427860
BGR-210DM-2A	10102601
BGR-3003-1D	10290521
BGR-3003-7A	10290522
BGX-100V-8	10108306
BLX-100-1ED	10290521
BLX-100-1FD	10410394
BLX-100-7	10349444
BLX-100-7B	10349444
BLX-102-1	10439745
CA-53W-1	71604130
CA-53W-1S	70603871
CA-61W-1	71604130
CA-61W-1Z	70603871
CA-61W-1Z	70603871
CBX-600-1	70630975
CBX-610B-8	70638486
CHR-100-1	10210960
CHR-100J-1B	10210960
CHR-200J-1B	10229584

Casio	Ref.
CHR-200WC	10229589
CHR-200WC-1	10236570
CMD-40-1U	10285353
CMD-40-1Z	70635826
CMD-40B-1Z	70635826
CMD-40D-1U	10285353
CMD-40E-1U	10285353
CMD-40F-7	10288212
CPW-300-1	70630975
CPW-500H-1	10426199
CPW-500H-9	10426199
DB-30-1	70603451
DB-30-9G	70603451
DB-31-1	70603451
DB-35H-1A	10022330
DB-35H-1B	10022330
DB-36-1A	10079756
DB-36-9A	10079756
DB-37H-1A	10090665
DB-37H-9A	10090665
DB-37HD-7	10090670
DB-53-1	70635749
DB-55-1	70635749
DB-55W-1	70635749
DB-58W	70643624
DB-58WG	70643624
DBA-80-1	70603451
DBA-80-N1	70603451
DBC-30-1Z	70635826
DBC-32-1A	10169264
DBC-32-9A	10169264
DBC-32C-1B	10169264
DBC-32C-1W	10169264
DBC-40-1	70635826
DBC-611-1	70649693
DBC-611E-1E	70649693
DBC-611G	70649742
DBC-62-1	70378364
DBC-81B	71603998
DBC-W150	71603998
DB-E30-1A	10090624
DB-E30D	10224688
DBP-25-1	70603451
DBX-103-1	10285353
DW 3000C-1	70368314
DW-003	10099273
DW-003B-1	71604122
DW-004C-1	71606395
DW-004C-1	10025152

Casio	Ref.	Casio	Ref.	Casio	Ref.	Casio	Ref.
DW-004VE	10108313	DW-6900CC-2	10332042	EF-118	10088612	EFM-502-1A4	10452265
DW-270	71604130	DW-6900HM-1	10410588	EF-305	10088682	EFR-515PB-1A	10404335
DW-280	70622792	DW-6900MR-7	10222653	EF-305-1A	10447496	EFR-519-1A4	10421436
DW-290	70622792	DW-6900PL-1	10410588	EF-305-9A	10447496	EFR-519-1A5	10421436
DW-290G-9	70622792	DW-6900SN-1	10243638	EF-308L-2A	10140042	EFR-519-7A	10421436
DW-290GMV-9	70622792	DW-6900SN-7	10222653	EF-308L-4A	10140042	EFR-523PB-1A	10431752
DW-402	70612257	DW-6900WW-7	10222653	EF-308L-7A	10140042	EFR-528D-1A	10443579
DW-403	70612257	DW-8300-1	70612257	EF-309D-1A	10132758	EFR-528RB-1A	10443579
DW-5000	71604348	DW-8300G-1	70612257	EF-309D-2A	10132758	EFR534BK-1A	10460032
DW-5000SL	71604348	DW-8400MB	71604349	EF-309D-7A	10132758	EFR-539D-1A	10473264
DW-5000SL-1	10512401	DW-8400Z	71604349	EF-320D-1A	10260346	EFR-539D-1A2	10473264
DW-5200C	71604348	DW-8700	71604349	EF-320D-2A	10260346	EFR-539D-7A	10473264
DW-5300	71604349	DW-8700G	71604349	EF-320D-7A	10260346	EFR-539RB-2A	10473264
DW-5300G	71604349	DW-9000	10099277	EF-341D-1A	10396075	EFR-539ZD-1A2	10473264
DW-5400C	71604348	DW-9000C-1	71606395	EF-341D-5A	10396075	EFR-543RBP	10493362
DW-5600	71604348	DW-9000C-1	10025152	EF-341D-7A	10396075	EFR546D-1A	10493237
DW-5600-9C	70360128	DW-9005	10099277	EF-514-1A	10249758	EFR-547BKG-1A	10500847
DW-5600B-1A	10202000	DW-9050C-1	71606395	EF-527D-1A	10447363	EFR547D-1A	10493252
DW-5600C	71604348	DW-9050C-1	10025152	EF-527D-5A	10447363	EFR547D-2A	10493252
DW-5600C-1	70360128	DW-9051-1	71606395	EF-527D-7A	10447363	EFR-549D-1A2	10505188
DW-5600E	71604348	DW-9051-1	10025152	EF-527L	10447480	EFR-549D-1A8	10505188
DW-5600E-1	10512401	DW-9052-1	71606395	EF-539-1A2	10330242	EFR-549D-1B	10505188
DW-5600EB	71604348	DW-9052-1	10025152	EF-539D-1A	10330242	EFR-549D-1B9	10505188
DW-5600EV	71604348	DW-9052-1B	71606395	EF-539D-1A4	10330242	EFR-549ZD-1A2	10505188
DW-5600FS-7	10222653	DW-9052-1B	10025152	EF-539D-1A5	10330242	EFR-549ZD-1A8	10505188
DW-5600SL	71604348	DW-9052-1C	71606395	EF-539D-1A9	10330242	EFX-501SP-1A	10357327
DW-5600SN	71604348	DW-9052-1C	10025152	EF-539D-2A	10330242	EMA-100-1A	10437955
DW-5600SN-1	10243638	DW-9052-2	10071727	EF-539D-4A	10330242	EMA-100B-1A4	10449650
DW-5600TB	71604348	DW-9400	10099273	EF-539D-7A	10330242	EMA-100D-1A	10438077
DW-5700C	71604348	EB-3002-N1	70377663	EF-539D-7A2	10330242	EQB-500D-1A2	10482540
DW-5700C-9G	70360128	EB-3011-7B	70605530	EF-539D-8A	10330242	EQB-500DB-2A	10482540
DW-5700CMV-1	70360128	EB-3011-7B	71604416	EF-539ZD-1A	10330242	EQB-500DC-1A	10482541
DW-5750E	71604348	ECW-M100D-1A	10302025	EF-539ZD-1A5	10330242	EQB-500RB-2A	10482541
DW-5900C	71604349	ECW-M100DB-1A	10302025	EF-539ZD-1A9	10330242	EQB-500RBK-1A	10482541
DW-5900CJ	71604349	ECW-M300DB-1A	10344744	EF-539ZD-7A	10330242	EQB-501DC-1A	10544176
DW-6000C	71604349	ECW-M300EDB-1A	10344744	EF-552-1A	10357533	EQB-501YDC-1A	10544176
DW-6000CJ	71604349	EDB-120-1VVCR	10124354	EF-552PB-1A2	10357533	EQS-500C-1A1	10360106
DW-6000G	71604349	EDB-300-2	10057055	EF-552PB-1A4	10357533	EQS-500C-1A2	10360106
DW-6000GJ	71604349	EDB-500-8A	10057000	EFA-120L-1	10224471	EQS-A1000DB-1A	10361977
DW-6200	71604349	EDB-501-8E	10057000	EFA-123-1A1	10268556	EQS-A1000RB-1A	10361977
DW-6200G	71604349	EDB-600D-8	10087181	EFA-124-1A	10268556	EQS-A500DB-1A	10427996
DW-6400C-1	70612257	EDB-600D-8D	10087181	EFA-124-7A	10268556	EQW-500BE-1A	10330787
DW-6600	71604349	EDB-610D-8	10087181	EFA-131PB-1A	10366009	EQW-500DBE	10304035
DW-6600C	71604349	EDB-610D-8C	10087181	EFA-131PB-1B	10366009	EQW-500DE	10304035
DW-6600G	71604349	EF-101-1A	10035372	EFA-131RBSP-1A	10366009	EQW-A1000B-1A	10361978
DW-6695	71604349	EF-101-2A	10035372	EFM-501D-1A	10415722	EQW-A1000DB-1A	10361977
DW-6695D	71604349	EF-101-7A	10035372	EFM-501D-7A	10415722	EQW-A1000RB-1A	10361977
DW-6900	10099273	EF-108	10088612	EFM-502-1A	10440282	EQW-A1200D-1A	10446275
DW-6900B	71604349	EF-117	10088612	EFM-502-1A3	10440282	EQW-A1200D-2A	10446275

Casio	Ref.
EQW-A1200DB-1A	10446275
EQW-A1200RB-1A	10446275
EQW-M1000D	10344245
EQW-M1000DB	10344245
EQW-M1000SV	10344245
EQW-M1100C-1A	10361978
EQW-M1100CG	10427100
EQW-M1100DB-1A	10361977
EQW-M600C-1A	10360106
EQW-M710L-1	10352757
EQW-T1010D	10344245
EQW-T1010DB	10344245
ERA-200D-1A	10439694
ERA-200DB-1A	10439694
ERA-200DB-1A9	10439694
ERA-200RB-1A	10439694
ERA-300D	10466383
ERA-300DB-1A	10466383
ERA-300DB-1A2	10466383
F-105W-1A	71604002
F-106W-1A	71604002
F-108WH-1A	10365960
F-108WH-2A	10365961
F-108WH-8A	10365985
F-108WHC-1	10409326
F-200W-1A	10075278
F-200W-9A	10075278
F-201W-1A	10075268
F-201W-9A	10075268
F-201WA-1A	10075268
F-201WA-9A	10075268
F-28W	71607366
F-28W-1	71607366
F-30-1A	10225997
F-30-1B	10225997
F-30-9	10225997
F-91W-1	71604002
F-91W-3Q	71604002
F-91WC-2A	10361901
FB-52W-1	70603451
FB-52WWMK-D1	70603451
FB-52WWTN-1	70603451
F-E10-1A	10057292
F-E10-1B	10057292
FE-10-2A	10057293
F-E10G-1A	10057292
FS-01LN-8E	71607452
FT-100W-1	70603871
FT-100W-1	71604130

Casio	Ref.
FT-500WC-3B	10074408
FT-600WB-5B	71607073
G-1000-1A	10287236
G-1000-7A	10287236
G-1000H-1A	10287236
G-1000H-9A	10287236
G-100-1B	10001449
G-100-2B	10001491
G-100-9B	10001449
G-100-9C	10001449
G-1010-1A	10287236
G-101-1A	10001449
G-1100B-1A	10287236
G-1100BD	10316353
G-1200B-1A	10287236
G-1200BD-1A	10353491
G-1200D-1A	10353474
G-1250B-1A	10287236
G-1250BD-1A	10353491
G-1250D-1A	10353474
G-1400-1A	10401141
G-1500-1A	10287236
G-1500B-5A	10287236
G-1500BD	10316353
G-1800D-1A	10257141
G-1800D-2A	10257141
G-1800D-3A	10257141
G-200-1E	10001449
G-2110-1	10001449
G-2110-2	10001491
G-2200-1	10025152
G-2210-1	71606395
G-2210-1	10025152
G-2300-1	10001449
G-2300-9	10001449
G-2310-1	10001449
G-2310-2	10001491
G-2400	10001449
G-2400-2	10001491
G-2900-1A	10093414
G-2900-1B	10093414
G-2900-2	10093417
G-2900BT-1	10093414
G-2900BT-10	10093414
G-2900BT-11	10093414
G-2900BT-12	10093414
G-2900BT-2	10093414
G-2900BT-3	10093414
G-2900BT-4	10093414

Casio	Ref.
G-2900BT-5	10093414
G-2900C	10093414
G-2900C-2	10093417
G-2900F-2	10093417
G-2900F-2V	10093414
G-2900F-3VVCR	10120803
G-2900V	10099277
G-2900V-2	10099273
G-3000-1	10062433
G-3001F-1	10062433
G-300-2A	10188556
G-300-3A	10188556
G-300-4A	10188556
G-300L-1A	10188737
G-300LV-7A	10212247
G-300ML-1A	10364887
G-3010-1	10062433
G-3011CC-1	10062433
G-3011F-1	10062433
G-301B-1A	10188556
G-301BR-1A	10188556
G-304RL-1A1	10216854
G-306X-1A	10188556
G-3100-1	10062474
G-3110-1	10062474
G-314RL-1A	10216864
G-315RL-2A	10220244
G-3310-1	10062474
G-350-2A	10188556
G-350-5A	10188556
G-353B-1A	10202000
G-500 (Alternativo)	10109619
G-500NM (Alternativo)	10109619
G-500XD (Alternativo)	10109619
G-501 (Alternativo)	10109619
G-501-1A	10109612
G-501-9A	10109612
G-501XD (Alternativo)	10109619
G-510D	10109619
G-510D-1A	10109619
G-511-1A	10109612
G-511-9A	10109612
G-511D-1A	10109619
G-511D-2A (Alternativo)	10109619
G-511D-7A	10109619
G-520D (Alternativo)	10109619

Casio	Ref.
G-520SCD (Alternativo)	10109619
G-521D (Alternativo)	10109619
G-521SCD (Alternativo)	10109619
G-531D (Alternativo)	10109619
G-540D (Alternativo)	10109619
G-541D (Alternativo)	10109619
G-542D (Alternativo)	10109619
G-550FB-1A3	10109612
G-550FB-1A4	10109612
G-550FD (Alternativo)	10109619
G-5600	71604348
G-5600-1	10512401
G-5600A-7	10222653
G-5600B-1	10512400
G-5600CC-2	10332042
G-5600E	71604348
G-5600E-1	10512401
G-5600KG-3	10403762
G-5600RB	71604348
G-5700	71604348
G-5700-1	10512401
G-5700B	71604348
G-5700RB	71604348
G-600-1A	10114988
G-610-3A	10114988
G-610-7A	10114988
G-611-2A	10114988
G-6900	71604349
G-6900A-7	10222653
G-6900KG-3	10403762
G-700-1A	10109612
G-700BD-7A	10183873
G-700D (Alternativo)	10109619
G-700NM (Alternativo)	10109619
G-701D (Alternativo)	10109619
G-701RD (Alternativo)	10109619
G-701SD (Alternativo)	10109619
G-702BD-1A	10183873
G-702LV (Alternativo)	10109619
G-7100BT-1	10134045
G-7100BT-10	10134045

Casio	Ref.
G-7100BT-11	10134045
G-7100BT-12	10134045
G-7100BT-2	10134045
G-7100BT-3	10134045
G-7100BT-4	10134045
G-7100BT-5	10134045
G-7100D-1	10183877
G-7100D-2	10183877
G-7100D-8	10183877
G-7100FT-1	10134045
G-7100FT-4	10134045
G-7100SC-2	10183877
G-7100SC-7	10183877
G-7300-1	10144012
G-7301G-9	10144012
G-731D (Alternativo)	10109619
G-7400-1	10173433
G-740D (Alternativo)	10109619
G-741D (Alternativo)	10109619
G-7500-1	10188485
G-7500G-9	10188485
G-7510-1	10188485
G-7600-1	10173433
G-7600-9	10173433
G-7700-1	10273059
G-7700BL	10303924
G-7710C-3	10288809
G-7800-1	10309325
G-7800B-1	10309325
G-7900-1	10330771
G-7900A-4	10332099
G-8100-1	10260080
G-8100-4	10260083
G-8100-7	10260085
G-8900-1	10347688
G-9000-1	10237942
G-9000-3	10237943
G-9000-8	10237944
G-9000MS-1	10318158
G-9000MX-8	10318153
G-9010-1	10299448
G-9100-1V	10270945
G-9200-1	10297191
G-9200GY-1	10395427
G-9300-1	10388870
GA-1000-1A	10435462
GA-1000-4A	10448982

Casio	Ref.
GA-1000-4B	10475505
GA-100-1A1	10347688
GA-100-1A2	10347688
GA-100-1A4	10347688
GA-100B-4A	10395226
GA-100B-7A	10395227
GA-100C-1A3	10347688
GA-100C-1A4	10347688
GA-100C-8A	10455781
GA-100CS-7A	10378391
GA-100L-8A	10527470
GA-100MB-1A	10347688
GA-110-1A	10347688
GA-110-1B	10347688
GA-110BC-7A	10395227
GA-110C-1A	10366716
GA-110FC-1A	10395226
GA-110GB-1A	10391028
GA-110HC-1	10378391
GA-110HC-1A	10378391
GA-110MB-1A	10347688
GA-110RG-7A	10395227
GA-110TS-1A4	10455781
GA-120-1A	10347688
GA-120B-1A	10378391
GA-120BB-1A	10347688
GA-150	10410443
GA-150MF	10410443
GA-200-1	10400762
GA-201-1	10400762
GA-300-1A	10347688
GA-700-7A	10540141
GAC-100-1A	10347688
GAC-100-1A2	10347688
GAC-100-8A	10429164
GAC-100BR-1A	10391028
GAW-100GA	10410443
GAX-100A-7A	10524998
GB-5600B-1B	10410588
GB-6900B-1B	10410588
GBA-400-1A	10479599
GB-X6900DB-1	10453473
GD-100-1A	10347688
GD-100-1B	10347688
GD-100GB-1	10391028
GD-100GB-1	10347688
GD-100HC-1	10378391
GD-100HC-1	10347688
GD-100HC-1A	10378391

Casio	Ref.
GD-100MS-1	10347688
GD-100MS-3	10347688
GD-100SC-1A	10378391
GD-100SE-1	10347688
GD-100WW-7	10395227
GD-110-1	10378391
GD-8900-1	10347688
GD-8900A-1	10347688
GDF-100-1A	10347688
GDF-100-1B	10347688
GDF-100BB-1	10347688
GDX-6900-7	10455174
GLX-150-1	10414667
GLX-5600-1	10292822
GLX-5600C-1	10467697
GPW-1000FC-1A	10486198
GPW-1000FC-1A9	10486198
GR-8900-1	10347688
GR-8900A-1	10347688
GS-1000J	10332054
GS-1001	10332054
GS-1010	10332054
GS-1050	10332054
GS-1050B-5A	10330743
GS-1100	10332054
GS-1150	10332054
GS-1300B-1A	10340823
GS-1400	10332054
GS-300	10332054
GS-300BW	10332054
GST-210B-1A	10502763
GST-210B-1A9	10502763
GST-210B-4A	10502763
GST-S100G-1A	10502763
GST-S100G-1B	10502763
GST-S110-1A	10502763
GST-S120L	10538348
GST-S130L-1A	10540150
GST-W100G-1B	10502763
GST-W110-1A	10502763
GST-W120L	10538348
GST-W130L-1A	10540150
GW-002BJ-1	10173433
GW-002E-1	10173433
GW-002J-1	10173433
GW-1400A-1A	10165470
GW-1400E-1A	10165470
GW-1400U-1A	10165470
GW-1401-1A	10165470

Casio	Ref.
GW-2000-1A	10287236
GW-2000BD	10316353
GW-2000BGD	10316353
GW-2300FP-4	10001449
GW-2310FB-1	10001449
GW-2500-1A	10287236
GW-2500B-1A	10287236
GW-2500B-5A	10287236
GW-2500BD	10316353
GW-3000B-1A	10287236
GW-3000BB-1	10378608
GW-3000BD-1A	10353491
GW-3000D-1A	10353474
GW-3000M	10287236
GW-3000M-4A	10370830
GW-300-1	10096986
GW-300A-1	10096986
GW-300CA-1	10096986
GW-300E-1	10096986
GW-300U-1	10096986
GW-301-1	10096986
GW-301-9	10096986
GW-330A-9	10096986
GW-3500B-1A	10287236
GW-3500BB-1	10378608
GW-3500BD-1A	10353491
GW-3500D-1A	10353474
GW-4000-1A2	10397960
GW-4000-2A	10397960
GW-4000A-1A	10397960
GW-500A-1D	10141364
GW-500E-1	10141364
GW-500U-1	10141364
GW-500Y-1	10141364
GW-530A-1D	10141364
GW-5600BCJ-1	10440757
GW-6900	71604349
GW-6900A-7	10222653
GW-6900BC	10440758
GW-6900KG-3	10403762
GW-7900-1	10330771
GW-7900B-1	10330771
GW-7900MS-3	10372544
GW-800-1	10242908
GW-810-1	10242908
GW-810H-2	10242908
GW-8900-1	10347688
GW-8900A-1	10347688
GW-8900TR-7	10395227

Casio	Ref.
GW-9000-1	10237094
GW-9000A-1	10237094
GW-9010-1	10299448
GW-9200-1	10297191
GW-9200J-1	10297191
GW-A1000-1A	10412716
GW-A1000D-1A	10415082
GW-A1000FC-1A	10450696
GW-A1000FC-2A	10431127
GW-A1000FC-2B	10431127
GW-A1000FC-3A	10450696
GW-A1000FC-5A	10450696
GW-A1000RAF-1	10415097
GW-A1100-1A	10443938
GW-A1100-2A	10482076
GW-A1100R-4A	10470476
GW-M500A-1	10141364
GW-M500F-1	10141364
GW-M500F-1C	10141364
GW-M530A-1	10141364
GW-M5600	71604348
GW-M5600-1	10512401
GW-M5600A-7	10222653
GW-M5600BC	10440758
GW-M5610	71604348
GW-M5610B-1	10512400
GW-M5610BA-1	10410588
GW-M5610BC	10440758
GW-M5610CC-2	10332042
GW-M5610KG-3	10403762
GW-M5610LY-1	10410588
GW-M850-1	10242908
GX-56-1A	10365763
GX-56-4	10365765
GXW-56-1A	10365763
GXW-56-4	10365765
HDA-100	10163349
HDA-600-1BL	10172242
HDA-600-7B	10172242
HDA-600-9B	10172242
HDA-600B-1B	10172242
HDA-600B-7B	10172242
HDC-600-1A	10179548
HDC-600-1B	10179548
HDC-600-2B	10179548
HDC-600-4B	10179548
HDC-600-7B	10179548
HDD-600-1A	10162532
HDD-600C-2A	10162540

Casio	Ref.
HDD-600G-9A	10162532
HDD-S100-1A	10395874
JC-10-1B	70377663
JC-11-1A	70377663
JC-11-1B	70377663
JC-30-3	70609863
JC-30-3VR	71604816
JC-30-9	70609863
JC-30-9VR	71604816
L-2W-1A	71605098
LA-11WB-1	71606922
LA-11WB-1A	71606922
LA-11WB-4	71606922
LA-11WB-4A	71606922
LA-11WB-7A	71606922
LA-2001-4A	10224495
LA-20WH-1AH	10393847
LA-20WH-1BH	10393847
LA-20WH-4AH	10393847
LA-20WH-9AH	10393847
LA-670WEGA-2	10335075
LA-670WEGA-9	10335075
LA-670WEGE-1	10433814
LA-670WGA-1	10335075
LA-670WGA-1Z	10335075
LA-670WGA-2	10335075
LA-670WGA-6	10335075
LA-670WGA-9	10335075
LA-670WGL-1	10433814
LAW-20-7A	10130954
LAW-20L-4A	10130771
LCF-10L-4A	10130771
LCF-20-7	10243217
LCF-21-1	10243166
LCF-30-1B	10332535
LCW-M100DSE-1A	10441305
LCW-M100DSE-2A	10441305
LCW-M100DSE-7A	10441305
LDF-10-1A	10243166
LDF-11-1A	10243166
LDF-11-7A	10243217
LDF-12-7A	10243217
LDF-20-1A	10243166
LDF-20-7A	10243217
LDF-20-7B	10243217
LDF-21-A	10243166
LDF-23-7A	10243217
LDF-30-4A	10289296
LDF-30-7	10289298

Casio	Ref.
LDF-31-7	10289298
LDF-50-7	10289298
LDF-52-7	10289298
LQ-110MV-1C	71605098
LQ-110MV-4C	71605098
LQ-110MV-7C	71605098
LQ-110MV-9C	71605098
LQ-112MV-7A	71605098
LQ-124-1B1	70603234
LQ-124B-1A	70603234
LQ-124B-7A	70603234
LQ-124B-9A	70603234
LQ-130MV-1B	71605098
LQ-139A-1B3	71605098
LQ-139A-1E	71605098
LQ-139A-1S	71605098
LQ-139A-7B3	71605098
LQ-139A-9B3	71605098
LQ-139AMV-1	71605098
LQ-139AMV-1B3	71605098
LQ-139AMV-1E	71605098
LQ-139AMV-9B3	71605098
LQ-139B-1B	71605098
LQ-139B-7E	71605098
LQ-139BMV-7E	71605098
LQ-139C-7B	71605098
LQ-139D-9B1	71605098
LQ-139E-1A	71605098
LQ-139E-5A	71605098
LQ-139E-9A	71605098
LQ-139E-9E	71605098
LQ-139EMV-9A	71605098
LQ-139FMV-7B	71605098
LQ-142-E-9	10088279
LRW-200H-1B	10406535
LRW-200H-1E	10406536
LRW-200H-2E	10406536
LRW-200H-2E2	10406535
LRW-200H-4E	10406535
LRW-200H-4E2	10406536
LRW-200H-7B	10406536
LRW-200H-7E1	10406535
LRW-200H-7E2	10406536
LRW-250H-4A	10435836
LRW-250H-7B	10435836
LRW-250H-9A1	10435836
LRW-250H-9A2	10435836
LTP-1302D-1A	10350275
LTP-1302D-7A	10350275

Casio	Ref.
LTP-1302L-1A	10350463
LTP-1358D-2A	10452019
LTP-1358D-4A	10452019
LTP-1358D-7A	10452019
LTP-2069D-1A	10468329
LW-200-1A	10129723
LW-200-1B	10129723
LW-200-2A	10128140
LW-200-4B	10239739
LW-200-7	10239740
LW-201-1A	10177113
LW-201-4A	10177113
LW-201B-2A	10184387
LW-201G-9A	10177113
LW-22H-1A	71604555
LW-22H-2	71604556
LW-22H-2A	71604556
LW-24HB-2A	10035480
LW-24HB-2B	10035480
LWA-M140-1A	10332535
LWE-11	10087098
LW-E11-1	10087089
LW-E11-2A	10087092
LW-S200H-1A	10360825
LX-600-1B	10163864
LX-600-1E	10163864
LX-610-1A	10572288
MCW-100H-1A	10452435
MD 703-1A	70368314
MD-528SG-7	70647999
MD-528SG-8	70647999
MD-753C-7A	70612257
MD-753C-7B	70612257
MD-753C-8A	70612257
MDV-100D-1A	10179834
MDV-100D-2A	10179834
MDV-100D-9A	10179834
MDV-106D-1A	10391237
MDV-106D-1A2	10391237
MDV-106D-7A	10391237
MDV-301-1AF	10264132
MDV-301-5AF	10264132
MDV-301-7AF	10264132
MDV-301D-1AV	10264131
MDV-301D-2AV	10264131
MDV-301D-7AV	10264131
MDV-501-1A	10264125
MDV-501-7A	10264125
MDV-501-9A	10264125

Casio	Ref.	Casio	Ref.	Casio	Ref.	Casio	Ref.
MDV-501D-1A	10264124	MQ-27-4G	71604416	MRP-100-2A	10217340	MTD-1080-1	10495560
MDV-501D-2A	10264124	MQ-336A-1A	70637562	MRP-100-5A	10217340	MTF-E001-1A	10328600
MDV-501D-7A	10264124	MQ-336A-7A	70637562	MRP-100-7A	10217340	MTF-E001-7A	10328600
MQ-104-1C	70605530	MQ-336A-7B	70637562	MRP-101-2A	10271024	MTF-E002-7A	10328600
MQ-104-1C	71604416	MQ-337A-1A	70637562	MRP-101-4A	10271024	MTF-E002B-7A	10328600
MQ-104-7C	70605530	MQ-337A-7B	70637562	MRP-700-1A	10212447	MTG-1000BR-1A	10292837
MQ-104-7C	71604416	MQ-405A-7B	70637562	MRP-700-2A1	10212447	MTG-1100B-1A	10292837
MQ-104-9C	70605530	MQ-405A-7E	70637562	MRP-700-2A2	10212447	MTG-1200B-1A	10292837
MQ-104-9C	71604416	MQ-44-1B	70605530	MRP-700-7A	10212447	MTG-1500B-1A1	10292837
MQ-24-1B	70605530	MQ-44-1B	71604416	MRP-700-9A	10212447	MTG-1500B-1A5	10292837
MQ-24-1B	71604416	MQ-44-7B	70605530	MRP-702-7A	10254303	MTG-900DA-8	10102363
MQ-24-1B2	70605530	MQ-44-7B	71604416	MRW-200H-1B	10393907	MTG-900DJ-4A	10102363
MQ-24-1B2	71604416	MQ-514AS-7A	70637562	MRW-200H-1B2	10393907	MTG-900DJ-8	10102363
MQ-24-1B3	70605530	MQ-514AS-7B	70637562	MRW-200H-1E	10393907	MTG-901-2A	10102363
MQ-24-1B3	71604416	MQ-58-7B	70605530	MRW-200H-2B	10393907	MTG-930D-8	10102363
MQ-24-1B3L	71604416	MQ-58-7B	71604416	MRW-200H-2B2	10393907	MTG-930DA-8	10102363
MQ-24-1E	70605530	MQ-71-1B	70605530	MRW-200H-3B	10393907	MTG-930DE-8V	10276757
MQ-24-1E	71604416	MQ-71-1B	71604416	MRW-200H-4B	10393907	MTG-930DU-8V	10276757
MQ-24-7B	70605530	MQ-71-2B	70605530	MRW-200H-4C	10393907	MTP-1169D-1A	10187731
MQ-24-7B	71604416	MQ-71-2B	71604416	MRW-200H-7B	10393907	MTP-1169D-7A	10187731
MQ-24-7B2	70605530	MQ-71-4B	70605530	MRW-200H-7E	10393907	MTP-1183A-1A	10471167
MQ-24-7B2	71604416	MQ-71-4B	71604416	MRW-200HB-1B	10438123	MTP-1183A-2A	10471167
MQ-24-7B3	70605530	MQ-76-1A	70605530	MRW-200HC-4B	10460283	MTP-1183A-7A	10471167
MQ-24-7B3	71604416	MQ-76-1A	71604416	MRW-S300H-1B	10452255	MTP-1183A-7B	10471167
MQ-24-7E	70605530	MQ-76-2A	70605530	MRW-S300H-1B2	10452255	MTP-1183PA-1A	10471167
MQ-24-7E	71604416	MQ-76-2A	71604416	MRW-S300H-1B3	10452255	MTP-1183PA-2A	10471167
MQ-24-7E2	70605530	MQ-76-7A	70605530	MRW-S300H-4B	10452255	MTP-1183PA-7B	10471167
MQ-24-7E2	71604416	MQ-76-7A	71604416	MSG-133L-1	10069755	MTP-1192-1A	10101197
MQ-24-9B	70605530	MQ-76-7A1	70605530	MSG-133L-2	10069757	MTP-1192-2A	10101197
MQ-24-9B	71604416	MQ-76-7A1	71604416	MSG-133L-2C	10069759	MTP-1192-7A	10101197
MQ-24-9B3	70605530	MQ-76-9A	70605530	MSG-135L-4	10102583	MTP-1192A-1A	10101197
MQ-24-9B3	71604416	MQ-76-9A	71604416	MTA-1010D-1A	10325804	MTP-1222A-1A	10151912
MQ-24-9E	70605530	MQ-93S-1A	70605530	MTA-1010D-2A	10325804	MTP-1222A-2A	10151912
MQ-24-9E	71604416	MQ-93S-1A	71604416	MTA-1010D-7A	10325804	MTP-1222A-7A	10151912
MQ-24CC-4B2	70605530	MQ-93S-7A	70605530	MTD-1050D-1A	10142001	MTP-1222A-7B	10151912
MQ-24CC-4B2	71604416	MQ-93S-7A	71604416	MTD-1050D-7A	10142001	MTP-1246D-1A	10198273
MQ-24CC-4B3	70605530	MQ-93S-9A	70605530	MTD-1051D-1A	10142001	MTP-1246D-2A	10198273
MQ-24CC-4B3	71604416	MQ-93S-9A	71604416	MTD-1051D-8A	10142001	MTP-1246D-7A	10198273
MQ-24CC-9B2	70605530	MQ-98-1B1	70605530	MTD-1057-1A	10264125	MTP-1247D-1A	10198286
MQ-24CC-9B2	71604416	MQ-98-1B1	71604416	MTD-1057-7A	10264125	MTP-1247D-2A	10198286
MQ-25-1	70605530	MQ-98-1B2	70605530	MTD-1057-9A	10264125	MTP-1247D-9A	10198286
MQ-25-1	71604416	MQ-98-1B2	71604416	MTD-1057D-1A	10264124	MTP-1258PD-1A	10471165
MQ-25-7	70605530	MQ-98-7B1	70605530	MTD-1059D-1A	10289330	MTP-1258PD-2A	10471165
MQ-25-7	71604416	MQ-98-7B1	71604416	MTD-1059D-2A	10289330	MTP-1258PD-7A	10471165
MQ-25-8	70605530	MQ-98-7B2	70605530	MTD-1059D-7A	10289330	MTP-1291D-1A1	10316645
MQ-25-8	71604416	MQ-98-7B2	71604416	MTD-1065B-1A	10406454	MTP-1291D-1A2	10316645
MQ-27-1	70605530	MRD-300D-1A	10271029	MTD-1066B-1A	10406454	MTP-1291D-1A3	10316645
MQ-27-1	71604416	MRD-300D-2A	10271029	MTD-1066D-1A	10357166	MTP-1291D-5A	10316645
MQ-27-4G	70605530	MRP-100-1A	10217340				

Casio	Ref.
MTP-1291D-7A	10316645
MTP-1300D-1AV	10350257
MTP-1300D-7A1	10350257
MTP-1300D-7A2	10350257
MTP-1303L	10350430
MTP-1303PL	10350430
MTP-1314SG-1A	10376150
MTP-1326D-1A	10389854
MTP-1326D-1A2	10389854
MTP-1326D-7A	10389854
MTP-1327D-1A	10389886
MTP-1370PL-1A	10450686
MTP-1370PL-7A	10450686
MTP-3050D-2A	10243873
MTR-100-1A	10237202
MTR-100-7A	10237202
MTR-102-1A1	10257862
MTR-102-1A2	10257863
MTR-102-7A	10257862
MTR-201-7A2	10277406
MTR-302-1A	10257854
MTR-302-1A1	10257873
MTR-302-7A1	10257873
MTR-302-7A2	10257855
MTR-501-1	10277405
MTR-501-2A	10277406
MW-57-7BVL	10224223
MW-57B-1BL	10224223
MW-59-1B	10108579
MW-59-1E	10108579
MW-59-7B	10108579
MW-59-7E	10108579
MW-600-1B	10572288
MW-600-7B	10572288
MW-600B-1B	10572288
MW-600B-7B	10572288
MW-600E-1A	10572288
MW-600E-2A	10572288
MW-600E-4A	10572288
MW-600E-7A	10572288
MW-600E-9A	10572288
MW-600F-1A	10572288
MW-60-1A	10108579
MW-60-7A	10108579
MW-61-1B	10108579
MW-61-7B	10108579
MWA-10-7B	70638486
MWB-10-7E	70638486
OC-100-1A	10074353

Casio	Ref.
OC-100-8A	10074353
OC-103-2A	10074353
OVW-100BJ-3A	10186038
PAG-240-1	10036571
PAG-240-1B	10036571
PAG-240-8	10378625
PAG-240B-2	10364866
PAG-240T-7	10368286
PAG-40-3	10036571
PAG-40-5	10036571
PAG-40-7	10036571
PAG-80-1	10186221
PAG-80L	10186053
PAS-201-1	10082003
PAS-400B (Alternativo)	10113393
PAS-400B-5	10113394
PAS-410B-5	10114608
PAW-1100-1	10186221
PAW-1100T-7	10250055
PAW-1200-3	10235374
PAW-1300-1	10262751
PAW-1500-1	10290989
PAW-1500T-7	10290995
PAW-2000-1	10332894
PAW-500-1	10299416
PRG-100-1	10245486
PRG-100-1A	10245508
PRG-100J-1	10245508
PRG-110-1	10262751
PRG-110Y-1	10307003
PRG-120-1	10275543
PRG-130-1	10290980
PRG-130Y-1	10338478
PRG-140-1	10299416
PRG-200-1	10332905
PRG-200A	10350859
PRG-240-1	10036568
PRG-240-1B	10036568
PRG-250-1	10390035
PRG-250B-3	10412634
PRG-260-1	10412702
PRG-270-1A	10450938
PRG-270-1E	10450942
PRG-270-2ER	10450940
PRG-270-4	10450942
PRG-300-1B	10443951
PRG-40-3	10036568
PRG-40B (Obsoleto)	10036575

Casio	Ref.
PRG-500-1	10350859
PRG-50-1	10078211
PRG-50J-1	10078211
PRG-50L-2	10078211
PRG-50L-3	10078211
PRG-510-1	10390035
PRG-550-1A1	10412702
PRG-550-1A1	10412703
PRG-550-1A9	10412704
PRG-550BD	10434672
PRG-600YB-3	10530879
PRG-70-1	10158340
PRG-70J-1	10158340
PRG-80-1	10186221
PRG-80J-2	10186221
PRG-80L	10186053
PRG-80T-7	10274176
PRG-80YT-1 Equivalente	10274176
PRG-90-1	10235342
PRS-200-1	10082003
PRS-200BC-1	10082003
PRS-201BC-1	10082003
PRS-400B-2	10113393
PRT-41SJ-1	10031024
PRW-1000J-1	10186221
PRW-1000LJ	10186053
PRW-100J-1	10186221
PRW-1200T	10231225
PRW-1300-1	10262751
PRW-1300J-1	10262751
PRW-1300T-7	10262763
PRW-1300Y-1	10307003
PRW-1500-1	10290980
PRW-1500J-1	10290980
PRW-1500T-7	10290991
PRW-1500YJ-1	10338478
PRW-2000-1	10332905
PRW-2000A-1	10350859
PRW-2500-1	10390035
PRW-3000-1A	10443951
PRW-3000-4E	10446383
PRW-3100FC-1	10516148
PRW-3100Y-1	10443951
PRW-3100Y-1B	10443951
PRW-3500-1	10412702
PRW-3500-Y-4	10491497
PRW-5000-1	10350859
PRW-500-1	10299416

Casio	Ref.
PRW-5050BN-1	10446399
PRW-5100-1	10390035
PRW-6000-1	10471929
PRW-6100FC-1	10516148
QB-500D-1A	10482540
RFT-100	10227760
RFT-100-1J	10227753
RFT-100-2	10227755
RFT-100-4J	10227753
RL-308L-1A	10140042
SDB-500W-1A	70610304
SDB-500W-1B	70610304
SDB-500W-1C	70610304
SDB-500W-1D	70610304
SDB-500WX-1A	70610304
SDB-500WX-1B	70610304
SDB-600-1	70641097
SGW-1000-1A	10500704
SGW-100-1	10304195
SGW-100B-3	10304188
SGW-200-1	10314276
SGW-200-1B	10314276
SGW-300H-1A	10360816
SGW-300HB-3A	10360774
SGW-300HD-1A	10300672
SGW-400H-1B	10360816
SGW-400H-1B2	10379562
SGW-400HD-1B	10300672
SGW-450H-1A	10500870
SGW-450H-2B	10500871
SGW-450HD-1B	10485930
SGW-500H-1B	10431875
SGW-500H-2B	10431876
SHE-3029L-7A	10458479
SHE-3503	10451775
SHE-4507GL-1A	10440338
SHE-5025BL-1A	10413328
SHN-5009L-4A	10322184
SKAW-590-1A	10273059
SPF-40-1	10045754
SPF-40-2 (Obsoleto)	10045755
SPF-40S-2	10158454
SPF-60-1A	10124594
SPF-60D-7A	10128087
SPF-60J-1A2	10124594
SPS-300C	10018048
SPS-300C	10093387
SPS-300C-2	10093390



Casio	Ref.	Casio	Ref.	Casio	Ref.	Casio	Ref.
SPW-1000-2	10231233	W-201G-9A	10162570	W-720G-9	71604130	W-755-1A	10179406
STB-1000-1	10463951	W-210-1A	10202335	W-720MV-1	70603871	W-755-2A	10257772
STB-1000-1A	10463951	W-210-1B	10202335	W-720MV-1	71604130	W-756-1A	10287400
STL-S100H-1A	10462707	W-210-1C	10202335	W-725-1	70622722	W-756-2A	10287401
STL-S100H-2A	10462707	W-210-1D	10202335	W-725-1A	70622722	W-76-7	70605530
STL-S100H-2A	10487314	W-210-2	10202336	W-725-9	70622722	W-76-7	71604416
STP-100J-1	10275316	W-211-1A	10268500	W-726B-1A	70622722	W-76-9	70605530
STR-100J-1	10075642	W-211-1B	10268500	W-726B-9A	70622722	W-76-9	71604416
STR-101-1	10075642	W-211-2A	10268501	W-727H-1A	71602198	W-800H-1A	10268612
STR-110J-1A	10075642	W-211-2B	10268502	W-728HD-1A	71604172	W-800HG-9A	10268612
STR-110J-9	10075644	W-211B-1A	10268507	W-729H-1A	71605241	W-85-2	70609863
STR-111-1A	10075642	W-212H-1A	10300101	W-729H-2A	71605241	W-85-2	71604816
STR-111-9	10075644	W-212H-2A	10300102	W-729HD-1A	71605241	W-86-1	71603087
STR-200-2	10083833	W-212H-9A	10300101	W-73-1A	70603451	W-86-1	71604153
STR-210	10130942	W-213-1A	10212268	W-73-1B	70603451	W-86-1	70603451
STR-300	10093317	W-213-2A	10212268	W-732H-2A	10040342	W-86-4	71604153
STR-300-1C	10375490	W-213-9A	10212268	W-732H-2C	10040344	W-86-4	70603451
STR-300-2A	10093326	W-214H-1A	10365955	W-732H-7A	10040344	W-87H-1	71602163
STR-300B-1	10093256	W-214H-4A	10365956	W-732H-7C	10040344	W-87H-1A2	71602163
STR-300C-1	10093317	W-214HC-1A	10409322	W-732H-9A	10040344	W-88H-1	71602163
STR-300C-2	10093320	W-214HC-7A	10409325	W-733-1A	10044139	W-93H-1A	71607653
STR-300CJ-1	10093317	W-215H-1A	10435844	W-733H-1A	10044139	W-96H-1A	10076822
STR-300J-1A	10093317	W-215H-1A2	10435844	W-733H-1A2	10044139	W-96H-1B	10076822
STR-300J-1B	10093317	W-215H-2A	10435865	W-735H-1A	10410723	W-96H-2A	10076822
STR-300J-1C	10093317	W-216H-1A	10365960	W-735H-1A2	10410723	W-96H-9A	10076822
STR-300S-1	10186122	W-216H-1B	10365960	W-735H-1A3	10410723	W-E10-2A	10071946
STR-400-1	10109302	W-42H-1A	10040373	W-735H-2A	10410726	W-E10-D	10071954
STR-400-2	10109304	W-43H-1A	10040373	W-735H-8A	10452133	W-E11-1-1A	10071912
STR-400J-1	10109302	W-43H-1B	10040373	W-740-1	71606712	W-E11-2A	10071929
STR-400J-2	10109304	W-50U-1	70603451	W-740-1	70377663	WL-500-1A	10109883
STR-500-1	10130931	W-520U-1	70603871	W-740B-8	70377663	WL-500-2A	10109883
STR-500J-1	10130931	W-520U-1	71604130	W-740G-9	70377663	WL-500-4A	10109883
STR-600-8	10141531	W-54US-1	70377663	W-740GMV-9	70377663	WL-S21H-1A	10125561
STR-800-1	10177127	W-57-1A	10033816	W-751-1	10128047	WL-S21H-1B	10125561
STR-900-1	10206164	W-57-1B	10033816	W-751-1	10128046	WL-S21H-2A	10125561
SWC-05-1	70360128	W-57-2A	10033816	W-751-2A	10128047	WL-S21H-4A	10125561
TGW-10-1	70607875	W-57-3A	10033816	W-751D-2A	10249379	WL-S21H-7A	10125561
TGW-10-7	70607875	W-59-1	70609863	W-751D-8A	10249379	WS-110H-1A	10047350
TR-400-2B	10114845	W-59-1	71604816	W-752-1A	10179406	WS-110H-1A2	10047350
TRT-100H-1A	10022765	W-60U-1	70607875	W-752-2A	10179407	W-S200H-1A	10360831
TRT-300-1	10033810	W-64-1	71604816	W-752-2B	10179406	W-S200H-1B	10360831
TRT-300-2B	10033811	W-64-1A	70609863	W-752-4B	10179406	W-S200HD-1A	10360838
TS-100-1	70610304	W-64-1B	70609863	W-752-9B	10179406	W-S210H-1A	10360831
W-101-1A	10111935	W-69HV-1A	10035459	W-753-1A	10179406	W-S220-1A	10395874
W-101-7A	10111935	W-69HV-1B	10035459	W-753-2A	10183358	W-S220-9A	10395874
W-110-1A	10243166	W-71-1	71604153	W-753-3A	10183359	W-S22C-7B	10452422
W-110-7A	10243166	W-71MV-1	71604153	W-754H-1A	10040344	WS-300	10018051
W-201-1A	10162570	W-720-1	70603871	W-754H-2A	10040344	WS-300-1B	10018051
W-201-2A	10162570	W-720-1	71604130	W-754H-7A	10040344	WS-300-1E	10128087

Casio	Ref.
WS-300-2E	10018048
WV-200A	10302043
WV-200A-2A	10302044
WV-200DA-1	10313689
WV-200DE-1	10313689
WV-200DU-1	10313689
WV-200E	10302043
WV-200E-2A	10302044
WV-200U	10302043
WV-57H-1A	10092505
WV-57H-1B	10092505
WV-57HA-1A	10092505
WV-57HA-1A2	10092505
WV-57HA-1B	10092505
WV-57HA-2A	10092505
WV-57HA-4A	10092505
WV-57HE-1A	10092505
WV-57HU-1A	10092505
WV-57HY-1A	10092505
WV-58A-1A	10243173
WV-58A-9A	10243173
WV-58DA-1A	10243172
WV-58DE-1A	10243172
WV-58DU-1A	10243172
WV-58E-1A	10243173
WV-58E-2A	10249714
WV-58J-1A	10243173
WV-58J-1AD	10243173
WV-58U-1A	10243173
WV-59A-1A	10272777
WV-59DA-1A	10272778
WV-59DE-1A	10272778
WV-59DU-1A	10272778
WV-59E-1A	10272777
WVA-104HA-1A	10101126
WVA-104HA-2A	10101126
WVA-104HA-4A	10101126
WVA-104HA-4A2	10101126
WVA-104HA-7A	10101126
WVA-104HA-7A2	10101126
WVA-104HA-8A	10101126
WVA-104HA-9A	10101126
WVA-104HDE	10101121
WVA-104HDU-2	10101121
WVA-104HDU-7	10101121
WVA-104HY-1A	10101126
WVA-104HY-7A	10101126
WVA-105H-1A	10101160
WVA-105HA-1A	10101160

Casio	Ref.
WVA-105HD-2A	10101156
WVA-105HDA-1A	10101156
WVA-105HDA-2A	10101156
WVA-105HDA-7A	10101156
WVA-105HDE-1A	10101156
WVA-105HDE-2A	10101156
WVA-105HDJ-2A	10101156
WVA-105HDU-2A	10101156
WVA-105HJ-1A	10101160
WVA-105HY-1A	10101160
WVA-106HA-1B	10187727
WVA-106HA-7B	10187727
WVA-106HA-9A	10187727
WVA-106HDA-1A	10179989
WVA-106HDA-2A	10179989
WVA-106HDA-2B	10179989
WVA-106HDA-4B	10179989
WVA-106HDA-7A	10179989
WVA-106HDE-1A	10179989
WVA-106HDE-2A	10179989
WVA-106HDE-2B	10179989
WVA-106HDJ-7B	10179989
WVA-106HDU-1A	10179989
WVA-106HDU-2A	10179989
WVA-106HDU-2B	10179989
WVA-106HDU-7A	10179989
WVA-106HE-7B	10187727
WVA-106HJ-1BH	10187727
WVA-106HU-1B	10187727
WVA-107HA-1A	10254396
WVA-107HDA	10254398
WVA-107HDE	10254398
WVA-107HDJ	10254398
WVA-107HDU	10254398
WVA-107HE-1A	10254396
WVA-107HE-1A2	10254396
WVA-107HJ-1AH	10254396
WVA-107HU-1A	10254396
WVA-107HU-1A2	10254396
WVA-109HA-1	10283660
WVA-109HE-1	10283660
WVA-109HJ-1	10283660
WVA-109HU-1	10283660
WVA-320J-1	10257901
WVA-430A-1A	10152407
WVA-430DA-2A2	10152395
WVA-430DE-1	10152395
WVA-430DE-2	10152395
WVA-430DE-7	10152395

Casio	Ref.
WVA-430DU-1A	10152395
WVA-430DU-2A	10152395
WVA-430DU-7A	10152395
WVA-430E-1A	10152407
WVA-430J-1A	10152407
WVA-430J-1A2	10152407
WVA-430TDE-1	10373237
WVA-430TDE-1A	10152433
WVA-430TDU-1A1	10152433
WVA-430TDU-1A2	10152433
WVA-430TDU-9A	10152433
WVA-430U-1A	10152407
WVA-470BE-1A	10152407
WVA-470DE-1A	10336259
WVA-470DE-2A	10336259
WVA-470DJ-1A	10336259
WVA-470E-1A	10152407
WVA-470J-1A	10152407
WVA-620E-1A2	10152407
WVA-M640-1A	10408444
WVA-M640-1A2	10408444
WVA-M640-7A	10408444
WVA-M640B-1A	10408444
WVA-M640B-1A2	10408444
WVA-M640D	10443230
WVA-M650-1A	10408444
WVA-M650-2A	10408444
WVA-M650B-1A	10408444
WVA-M650B-1A2	10408444
WVA-M650D	10443230
WV-M120D	10336258
WV-M120E-1	10152407
WVQ-142DA-2A	10257816
WVQ-142DE-1A	10261191
WVQ-142DE-2A	10261191
WVQ-142DU-1A	10261191
WVQ-142DU-2A	10261191
WVQ-142E-7E	10257901
WVQ-143E-1A	10242631
WVQ-143E-4A	10242631
WVQ-400E	10152407
WVQ-550DA-1A	10242640
WVQ-550DBA-1A	10242640
WVQ-550DE-1A	10242640
WVQ-550DE-2A	10242640
WVQ-550DE-4A	10242640
WVQ-550E-1A	10242631
WVQ-550LE-9A	10242631
WVQ-560A-1A	10242631

Casio	Ref.
WVQ-560DE-1A	10242603
WVQ-560DE-2A	10242603
WVQ-560DE-7A	10242603
WVQ-570DBE-1A	10272981
WVQ-570DE-1A	10272981
WVQ-570DE-2A	10272981
WVQ-570E-1A	10242631
WVQ-M410-1A	10408444
WVQ-M410DE	10443230
WV-5100C	71604348

